

With EXELTOP™
focus on your own performance

GAIN PERFORMANCE

Intuitive to use - ensures accurate and stable gas flow.

SAVE TIME

Ready to use due to the built-in regulator and on/off lever - quick connect available for all gases.

SAVE MONEY

No need to buy and maintain a separate regulator - regular checks by Air Liquide.

SAVE GAS

No gas loss thanks to the on/off lever - check content at a glance with the permanent pressure gauge.

WORK SAFELY

Emergency cut-off - Protected valve - No more exposure to high pressure gas flow.



Contact

Air Liquide
Industrial Merchant
75, quai d'Orsay
75321 Paris Cedex 07
FRANCE




World leader in gases, technologies and services for Industry and Health, Air Liquide is present in 80 countries with close to 50,000 employees and serves more than 2 million customers and patients. Oxygen, nitrogen and hydrogen have been at the core of the company's activities since its creation in 1902. Air Liquide's ambition is to be the leader in its industry, delivering long-term performance and acting responsibly.



EXELTOP™

Trust in performance



EXELTOP is Air Liquide's trademark. October 2013 - Design ps00003

www.airliquide.com

EXELTOP™

Ensure superior results



Advanced two-stage built-in regulator

- No need to buy a separate regulator
- No more exposure to high pressure gas flow
- Accurate outlet pressure or flow rate
- Precise setting with a new graduated handwheel

Quick connect system

- Available for all gases
- Simply connect the hose and get to work



Ergonomic and shock-absorbing cap

- Easy handling
- Simple access to all functions
- Permanent, reliable protection for the valve and regulator

Newly designed on/off lever

- Immediate gas cut-off
- On/off status at a glance

Permanent content gauge

- At a glance content monitoring
- Get a reading even when flow is stopped



Instructions

1 Connect the hose



2 Check that the graduated handwheel is at zero



3 Open the on/off lever



4 Set the outlet pressure or flow rate



You are ready to go!
Check the instruction manual for detailed information